



RECOMMENDED TOOL KIT

- 1) 7/16" Wrench
- 2) 3/4" Wrench (for #45 & # 33 trolleys)
- 3) Steel file
- 4) Carpenter's square
- 5) Chalk line reel
- 6) Measuring tape
- 7) Pencil
- 8) 3/8" drill
- 9) 1/2" concrete drill (for 3/8,, concrete shields)
- 10) Small vise-grip (to tighten rods if rods are installed in concrete shields)
- 11) Large vise-grip (for dog legs)
- 12) Ratchet with 9/16" & 1/2" sockets
- 13) Transit
- 14) #2 square recess bit (for self-tapping screws)
- 15) Iron saw
- 16) Hammer (for alignment pins)
- 17) Flat screwdriver (for alignment pins)
- 18) Rubber mallet
- 19) Flat crow bar
- 20) 5/16" Allen key (for escapement tracks)
- 21) White Lithium grease (paste; not spray)